
R53 VERTEX


1	Profiles and accessories
2	Profiles and accessories
3	Glazing screws
4	Mounting of skylight roof T-joint
5	Mounting of skylight roof T-joint, 0-frame
6	Alternative mounting of skylight roof T-joint glazing lists
7	Ridge mounting with two profiles
8	Ridge mounting with profile R53-956-290 (90°)
9	Mounting of the top of quadrilateral pyramidal roof
10	Mounting of the top of polygonal pyramidal roof
11	Angle joints assembly of hip roof
12	Skylight roof joining with R54 structure
13	Joining with building frame
14	Adjustable eaves profiles
15	Barrel vault joining with frame structure
16	Barrel vault joints manufacturing
17	Joints manufacturing
18	Opening skylight and joining with structure
19	Opening skylight, Vertical section 1:2
20	Opening skylight, Horizontal section 1:2
21	Opening skylight, Angle joints 1:2
22	Opening skylight, Hinge fastening and machining 1:2
23	Opening skylight, joing with separate frame and joining with triplex structure
24	Opening equipments of shutter
25	Expansion joint
26	Glazing
27	Glazing
28	Glazing. Glass selection. Glazing instructions

Use of cover plates







Frames on separate frames




Horizontal frame R53-950-Fe









Inside glazing bead R53-526








optionalangle T-joint profile R53-428

36



Auxiliary profile 2k->3k R53-520



Heat-insulating profile R53-604 length 6,6 plastic



Heat-insulating profiles R53-605 length 6,6 plastic



Joint profile R65-428







Skylight window hinge R53-712



Sealing

Butyl tapes















* Ex factory







Corners





Fixing of R53-520 profile




Countersunk head tapping screw 4,2x25 C/C 200 DIN 7981 A2








R53



















R53









Cross-cutting of outside cover profiles / capping

Note! This structure type functions only with certain angless.


Selection of external and internal glazing beads


Outside:						
		Roof fall		β		
layout	α	30°	45°	60°		
quadradangle	90°	R53-220	R53-230			
Inside:						
quadragangle	90°	R53-523	R53-524			














Selection of external and internal glazing beads


Outside:					
		Roof fa	all	β	
layout	α	30°	45°	60°	
Hexagon	120°	R53-215	R53-220		
Octagon	135°	R53-11363	R53-215	R53-220	
Dodecagon	150°		R53-11363	R53-215	
Inside:					
Hexagon	120°	R53-522	R53-523		
Octagon	135°		R53-522	R53-523	
Dodecagon	120°			R52-522	


01.07.2013







Note! Profile sizes of horizontal and vertival frames joining with angle profile of hip or pyramid must be smaller than frame profile so that joints align correctly.







Angle assembly of hip or pyramid with one profile Horizontal/vertical profile joints with angle profile














SPECIAL ATTENTION must be paid to joints between Building frame and skylight roof.














01.07.2013

R53 VERTEX 14












Assembly of barrel vault's A joint








01.07.2013







Extension of vertical profile




Making joint with sealing profile






Skylight max/min sizes (H/L)




01.07.2013

R53 VERTEX 18










01.07.2013








Opening skylight Angle joints 1:4








Note! Installation of heat and smoke venting devices in according with manufacturer's instruction.





Joining with triplex structure 1:2

Joining with separate frame 1:2


MOTOR OPERATED

Mountings

-twist rivet M6 + screw

Control automatism


- -Control center max. 10 engines/centre
- -Transformer for engine
- -Control switch for single / group control
- -Group center with alarm automatism
- -connection for ex. at fire station
- -Rain sensing device
- -Wind sensing device
- -Smoke indicator
- -Fire indicator
- -Fire alarm handle





Stem engine
MINGARDI-MAGNETIC (Stig Wahlstrum Oy)


Operate voltage 24 V DC
Opening 180...1000 mm depending on type
Weight of shutter -with one engine max. 80 kg
-with two engine max. 160 kg



01.07.2013







Installation

Great care must be used when installing glass and insulation glass onto roofs. The installation base must be completely straight and the contact with the glass must be good. The sealing materials used in the installation must be compatible with each other and must not create any chemical reactions. Care must be used with the edges of the glass, since damaged edges have a major impact on the durability of the glass The glazing bead profiles are attached with a steady force, using a torque wrench, for instance.

When starting the glazing, make sure that the rebates, glazing beads and glasses are clean. Condensation and run-off water grooves must be clean and open and the thickness of the glass must be correct.

Sealing tape 643 is set into place and the corners are secured with elastic compound. When cutting the sealing tape, it must be kept in mind that there is a possibility of 5 mm/m longitudinal shrinkage.

Installation of glass

The purpose of the pads is to support, center and carry the sealed glass or similar in the frame in the intended manner. With the bearing pads, the weight of the glass is partially shifted to the frame structure. Ensure that the pads remain in place. The bearing pads must made of a shape-retaining and durable plastic with a hardness of 70-90° Shore A, or another suitable material for the purpose.

Pads made of other material must be of an equal hardness. A disjointable or folder pad can not be used.

The temperature fluctuations that the R53 VERTEX structures may be susceptible to must not effect the hardness of the pads. The length of the bearing pads must be 100 mm, and the width of the pad must be 4 mm wider than the thickness of the glass pane. The thickness of the bearing pads is 5 mm. A pad must also be under the outermost glass. The length of the support pads can be 50...100 mm depending on size of glass pane, and the width of the pad can be same as the width of the bearing pad. It must be ensured that the supporting pads remain in place. The bearing and supporting pads must not block the the run-off water grooves at any point. The pads are installed 100 mm from the corner of the pane (measured to the center of the pad) .

Instead of heat-insulating profile under the pads of heavy glass, it of recommended to use a piece (approx. 200 mm long) of the R53-520 profile. In triplexstructure is used pad R53-603.

These glazing itroductions are a matter principal only. Naturally, we are not responsible for the actual glazing work which we do not control.

The EPDM sealing compound tape we supply is very heat and age-resistant, we are not responsible for the sealing compound materials. The thickness and types of glass must be specified separately with the glass manufacturer. Special instructions, e.g. RIL 198, Light permeable structures. Note the thickness of the glass packages. Roof glazing instructions are valid for areas 5-75°. Transparent structure 75-90° are window structures.




How to glaze R53 VERTEX-profiles

Rectangular roof and oblique angled applications

☐ Ensure that condensation and leakage grooves are	Ш	The adherence of the butyl tape and the success of
clean		the glazing cannot be quaranteed in temperatures
☐ Ensure that the frame structure joints have been done		lower than 0° C.
in accordance with NOKIAN's instructions (work shop files)		Pull the butyl tapes at the X- and T-joints over each
☐ make sure that the corners of the T-joint are sealed;		other to ensure the corners are sealed.
there must not be any putty in the leakage or		install the glazing sealing to the exterior glazing
condensation grooves, only and especially in the places		bead R53-2XX.
where it is specified (engine shop file).		the sealing tape must not be stretched when applying
☐ Mount interior vertical glazing profiles R53-52X into		it; remember that there is a longitudinal shrinkage
place.		possibility of approx. 5 mm/m.
☐ Mount interior glazing sealing 643 into place; putty		Cut the sealing tape at a slant to prevent overlapping
the sealing corners with the glass manufacturer's		of the sealing "legs".
recommended elastic compound.		First mount the vertical glazing bead profiles into place
☐ set glazing pads into place, 100 mm from the edge		Open the holes in the butyl tape at the glazing bead
of the glass to the center of the pad. Pads must not		screw positions to prevent rotation of butyl tape
block leakage water grooves. Use elastic compound to		around glazing screws.
ensure that the pads remain in place.		Attach the glazing bead stainless special anchoring
-THE USE OF A DISJOINTABLE OR FOLDER PAD IS		screws in sequence starting from the end of the profile
STRICTLY FORBIDDEN.		to ensure the seal.
Under heavy glass, it is recommended to use		Mount the vertical glazing profiles into place in the
200 mm long pieces of profile R53-520 at the pad		same manner.
position (double structure), triplex structure R53-603.		Seal the joints of the glazing beads with elastic
-Asymmetrical pads (e.g. in barrel vaults) shaped from		compound and install cover piece R53-7XX into place
weather-resistant formwork plywood.		according to instructions.
☐ The thickness of the glass must be measured in		Extreme caution must be used when glazing so that
accordance with NOKIAN's instructions; glass thickness		the structure is definitely sealed.
4-8 mm in simplex structures, 25-27 mm in duplex		Perform the work in the proper sequence to prevent
structures, and 45-48 mm in triplex structures.		unnecessary stoppages.
THESE THICKNESSES ARE MINIMUM.		The special RT card instructions must be followed
-The manufacturer must determine the correct (e.g.		in glazing.
RIL 193-1993) thicknesses of individual glass elements		future information is available from
included in sealed glass packages in each instance.		Nokian Profiles.
☐ Lift the glass to the light opening area and senter it		
in the opening using the supporting pads.		
☐ Install butyl tape into place (e.g. using a rubber roller).		As the glazier, you are ultimately responsible for
☐ the surface of the glass must be absolutely dry and		the functionality of the structure.
clean to ensure that the butyl adheres.		the functionality of the structure.
·		









Cover plates R53-732 R53-730 R53-731 R53-733 R53-206 R53-730 R53-731 R53-733